

## RUP Dicamba Application Record 2019

(This form is an example developed by NDA. No specific format is required as long as the information below is recorded)

Complete **both** pages of this template for each application<sup>1</sup> of Engenia, XtendiMax, or Fexapan

### Prior to Application

Applicator Name: \_\_\_\_\_ NE Applicator ID NEB \_\_\_\_\_

Applicator Address: \_\_\_\_\_

Name of Property Owner/Renter: \_\_\_\_\_

Address of Property Owner/Renter: \_\_\_\_\_

\_\_\_: Purchase Receipt for RUP Dicamba Product

\_\_\_: Copy of Product Label

\_\_\_: Completed Auxin-specific training- Date: \_\_\_\_\_ Location: \_\_\_\_\_

Name of Presenter or Organization: \_\_\_\_\_

\_\_\_: Sensitive Crop Awareness<sup>2</sup>: Dates-Fieldwatch: \_\_\_\_\_ Crop Survey Date and Person Doing Survey: \_\_\_\_\_

\_\_\_: Endangered Species Protection Bulletin Date: \_\_\_\_\_

\_\_\_: Date the field was planted \_\_\_\_\_

### Application Details

Location of Field/Application: \_\_\_\_\_

RUP Dicamba Product Applied : \_\_\_\_\_ EPA Reg. Number: \_\_\_\_\_

Date of Application: \_\_\_\_\_ Crop Treated: \_\_\_\_\_ Target Pest: \_\_\_\_\_

Size of Treated Area: \_\_\_\_\_ Total Amount of RUP Dicamba Product Applied: \_\_\_\_\_

Rate of Dicamba Product Applied: \_\_\_\_\_ Nozzle Used<sup>3</sup>: \_\_\_\_\_

Pressure at the Nozzles: \_\_\_\_\_ (PSI) Method of Disposal: \_\_\_\_\_

\_\_\_ Pre or \_\_\_ Post-emergence application

If Post-emergence application, number of days application was made after planting: \_\_\_\_\_

Buffer Requirements/Calculations<sup>4</sup> (see page 2 for space to sketch a map):

\_\_\_\_\_

\_\_\_\_\_

Tank Mix Partners-Products	EPA Registration Number <sup>5</sup>	Rate of Application

### Spray Conditions (at boom height)

Start:

Time: \_\_\_\_\_ Wind Speed/Direction: \_\_\_\_\_ Air Temp: \_\_\_\_\_

Finish:

Time: \_\_\_\_\_ Wind Speed/Direction: \_\_\_\_\_ Air Temp: \_\_\_\_\_

Comments on any changes of wind direction during application:

\_\_\_\_\_

\_\_\_\_\_

## Spray System Cleanout<sup>6</sup>

Date of Cleanout: \_\_\_\_\_

1. After last load, drain the sprayer immediately.
2. Flush tank, hoses, boom, and nozzles with clean water.  
Open boom ends and flush if so equipped.
3. Inspect and clean all strainers, screens, and filters.
4. Using commercial sprayer cleaner containing strong detergents according to the manufacturer's directions wash all parts of the tank, including the inside top surface. Start agitation in the sprayer and thoroughly recirculate the cleaning solution for at least 15 minutes. All visible deposits must be removed.
5. Flush hoses, spray lines, & nozzles with the solution for at least 1 minute.
6. Remove nozzles, screens, and strainers, and clean separately in the solution.
7. Drain pump, filter, and lines.
8. Rinse the interior and exterior of the entire spray system, including the boom with clean water.
9. All rinse water must be disposed of at target site or captured and reused for solution as water in the next load of dicamba.

Before:

After:

_____	_____
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____

---

Space provided for map or buffer calculation

### FOOTNOTES

<sup>1</sup> A separate application record must be completed for each different field applied, and if a single field was applied over more than one day, there must be separate records made for each day's application.

<sup>2</sup> Both FieldWatch and the Crop Survey must be done. Keep this recorded information about sensitive and neighboring crops/sites with the application record.

<sup>3</sup> Include the entire name or code for the nozzle, do not just write Engenia, dicamba, brown or 001.

<sup>4</sup> The term "Buffer Calculation" refers to the distance inside or outside of the target area border where a buffer was required and maintained during the application. Records must either describe the buffer kept, or a map showing the buffer must be kept.

<sup>5</sup> EPA Registration Numbers for all pesticides in the tank mix must be recorded.

<sup>6</sup> RUP Dicamba labels require the spray system be cleaned out following all steps indicated on the label, at a minimum before the first application of dicamba, and either at the end of each dicamba application, or whenever the spray equipment is being used for a different spray tank mix.